

Mumby®

MANUFACTURING LTD.

RV HITCH ADAPTER

Installation Instructions



TOOLS REQUIRED

- ❖ 1/4" HEX WRENCH
- ❖ 3/4" SOCKET and EXTENSION
- ❖ 1/2" DRIVE RATCHET

INSTALLATION INSTRUCTIONS

- I. Bolt kingpin block onto kingpin, with the solid face of the block in the front and the back, as shown in the above picture. Tighten securely.
- II. Tighten set screws.
- III. Slide the column over the kingpin block, and from underneath, insert 4 bolts (1/2" x 2" with lock washers) inside and tighten. Make sure top plate of column has tightened up to kingpin plate. If it hasn't tightened, the bolts must be removed and a nylon wear washer (available at any RV dealer) needs to be inserted between the column and the kingpin plate and the bolts re-inserted and tightened.
- IV. Insert ball coupler into the column and fasten with the remaining 4 bolts and star washers.
- V. Tighten bolts to complete installation.

NOTE: Safety chains (Not supplied) need to be bolted to holes, pre-drilled in the column.

Phone: 306 682-1477 Toll Free: 888 682-1477 Fax: 306 682-2028

Email: mumbyhitches@sasktel.net