



**It's all-new for 2014!
Removable Ball Gooseneck Hitch for the 2013
Dodge 3500 & 2014 Dodge 2500
(and newer models).**

Attaches in 3 easy steps!

Mumby's gooseneck hitch is fastened directly to the factory installed cross-member without removing the fender wall liners. It is simple and with 3 easy steps you can have the Mumby Hitch installed.

- 1. Drill the receiver and release holes in the floor of the truck.**
- 2. Slide the two fastening plates into place.**
- 3. Bolt the gooseneck hitch through the factory cross member, to the fastening plates installed in step 2 and then tighten bolts.**

It's that simple! With our long-standing reputation for strength, simplicity and convenience...and a new, low price....why look any further than Mumby for your towing requirements?